


Installation Instruction

Aluminum Performance bar front NC



Picture1


To install the front performance bar please loosen the screws on positions 1-5 and remove the OEM metal bar. (Picture 1)

When installing the aluminum performance bar please use the OEM screws (Picture 2). For positions 5 (1 piece) and 17 (3 pieces) please use the supplied nuts.



Picture 2

Please check if al nuts are tightend and torque them (see torque table)



Picture 3



Installation Instruction

Aluminum Performance bar front NC NC0-0963

Torque table:

 $1 \rightarrow 17,7 - 26,5 \text{ Nm}$

 $2 \rightarrow 17,7 - 26,5 \text{ Nm}$

 $3 \rightarrow 17,7 - 26,5 \text{ Nm}$

 $4 \rightarrow 17,7 - 26,5 \text{ Nm}$

 $5 \rightarrow 3 - 5 \text{ Nm}$

 $17 \rightarrow 3 - 5 \text{ Nm}$

When installing the small engine under tray please also install the retaining plate for correct functionality of the inspection flap. (Pictue 4)



Picture 4