




# Installation Manual

## Handle for dipstick


NCD-301259

02.2019

Take the dipstick from its position in the engine bay.  
Clean the dipstick and check for play, you should be able to move the dipstick a little.



pic 1



pic 2

Remove the original handle from the dipstick by driving out the small pin from the handle with a 1,5mm Ø punch. (pic 1)

When you have removed the pin, please also remove the original rubber ring from the handle and reuse it on your new handle (pic 2)

Slide the dipstick in the new handle and secure the two parts by driving the small pin in the opening on the new handle. (pic 3)



pic 3